WALL/KILN SPACING: 12" [30.5cm] SPACING BETWEEN SIDES OF KILN AND WALLS OR OTHER OBJECTS. 18" [45.7cm] IS RECOMMENDED. LEAVE AT LEAST 18" [45.7cm] BETWEEN TWO KILNS.

AMBIENT VENTILATION: SEE CHART BELOW FOR RATINGS. TO CALCULATE

REQUIREMENTS, SEE hotkilns.com/calculate-kiln-room-ventilation.

KILN VENTILATION: L&L VENT-SURE KILN VENT RECOMMENDED FOR SAFETY

AND LONGER ELEMENT LIFE. OPTIONAL CONTROL ALLOWS VENT TO BE TURNED ON AND OFF WITH CONTROL.

MADE FROM

NEW

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF L&L KILN MFG INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF L&L KILN MFG INC. IS PROHIBITED.

DRAWN BY DATE

SCALE

5

DSL 05/01/20 1:18

OTHER INFO: REFER TO INSTALLATION INSTRUCTIONS AND CAUTIONS INSTRUCTIONS FOR OTHER REQUIREMENTS AND SAFETY INFORMATION. REFER TO WIRING DIAGRAM FOR ELECTRICAL HOOKUP INFORMATION.

MAX LOAD WEIGHT: SEE hotkilns.com/load-weight WEIGHT OF KILN: 1985 LBS, 900 KG

T3445-BL (3" BRICK) DAVINCI BELL-LIFT GENERAL DIMENSIONS

CLEARANCES, LAYOUT & INSTALLATION

LIKINS SWEDESBORD NJ 08085 REV SHEET OF DRAWING NO.

1/4 | 300-001-65

PH: (856) 294-0077 FAX: (856) 294-0070







